



# The MUV

CT029




## Owner's Manual

MODEL # CT029 / The MUV

| DESCRIPTION            | QTY.   |
|------------------------|--------|
| <b>CAR TENT</b>        |        |
| 100% Polyester         | 1 ____ |
| <b>POLES</b>           |        |
| Fiberglass Pole; Black | x ____ |
| <b>STAKES</b>          |        |
| Metal                  | 4 ____ |
| <b>CARRY POUCH</b>     |        |
| 100% Polyester         | 1 ____ |

### ASSEMBLY INSTRUCTIONS



#### STEP 1:

Confirm product contents by emptying contents of bag(s) and confirming all parts are included and undamaged.

#### STEP 2:

Select a smooth level site and spread out your tent.

#### STEP 3:

There are 2 poles that are bent into a U shape 1 long one and 1 shorter one.  
Thread the longer one (**figure D**) through the pole sleeve over the rear wheels and insert the ends into the pole pockets (**figure A**) located in front of the rear wheels.  
Thread the shorter pole (**figure C**) through the pole sleeves located over the front wheels and insert the ends into the pole pocket (**figure A**) located behind the front wheels.  
poles. Note: The clips at the front and rear of the tent should be attached BELOW the front and rear poles.

#### STEP 4:


There are 2 short straight poles with narrow ends. (**figure E**)  
Take these poles and insert them through the pole sleeves above the doors and insert the narrow tips through the brass grommets below the pole clips sewn into the tent.

#### STEP 5:

Now take one of the longest poles that have multiple bends to it and insert the poles into the pole pocks (**figure A**) at the end of one long side. Note: The end that goes to the front has the shortest section before the first bend in the pole.  
Repeat this for the other pole.

#### STEP 6:

The last step is to attach all of the pole clips (**figure E**) to these longer poles. Note: The clips at the front and rear of the tent should be attached BELOW the front and rear poles.



For questions, concerns or replacement parts call Gigatent at our Toll Free Number: 877-836-8701 Monday-Friday 9am-5pm EST or email us at [customerservice@gigatent.com](mailto:customerservice@gigatent.com)

#### WASHING & CARE INFORMATION

Hand wash using a mild dishwashing soap and soft sponge, then allow the fabric to completely air dry. To prevent mold or mildew do not store wet or damp.

**WARNING :**  
NEVER LEAVE CHILDREN UNATTENDED.  
WINDY CONDITIONS MAY UPROOT THE  
TENT. ALWAYS STAKE DOWN TENT.  
ADULT SUPERVISION REQUIRED.  
AGES 3 AND UP RECOMMENDED.

#### CAUTION:

This product was not designed to be left out in the sunlight for extended periods of time. Prolonged UV exposure will rapidly break down the fabric of this product. UV damage is not covered under our warranty

#### WARNING:

Keep all flame and heat away from tent and tent fabric.  
This tent meets flammability requirements of CPFA -84 .  
THIS TENT IS NOT FIRE PROOF.  
IF LEFT IN OPEN FLAME THE TENT WILL BURN.

#### CAUTION:

Never use any fuel-burning or oxygen-consuming devices, or any devices that produce fumes, including stoves, lanterns, candles, hibachis or heaters in or around your tent. This can result in carbon monoxide poisoning, injury or death

Contents and colors may vary.  
Please retain package for  
future reference.

  
Manufactured in China for  
Gigatent  
55 Haul Rd  
Wayne, New Jersey 07470  
[www.gigatent.com](http://www.gigatent.com)  
1-877-873-8601

TO VIEW FULL SELECTION OF OUR  
PLAY TENT PRODUCT LINE,  
GO TO [WWW.GIGATENT.COM](http://WWW.GIGATENT.COM)

STYLE #: CT029



## Manufacturer's Warranty

Warranty covers product to be free from defects in material and workmanship for 14 days after date of purchase.

Warranty does not cover natural breakdown of materials that occur inevitably with extended use (e.g., UV damage, exhausted zippers, defects caused by accident, abuse, alteration, animal attack, storm damage, misuse or improper care).

This product is covered for 14 days from date of purchase. Please check all contents to verify product has no missing or broken parts. Gigatent will mail replacement parts free of charge within the 14 Day Manufacturer's Warranty by calling 1-877-836-8701 or emailing [customerservice@gigatent.com](mailto:customerservice@gigatent.com). We highly recommend logging on to our website at [www.gigatent.com](http://www.gigatent.com) should you need customer service. Any parts in need of replacement after the 14 Day Manufacturer's Warranty can be purchased for a reasonable charge, plus shipping and handling. We require that products accepted for any repair must be properly cleaned according to our care instructions.

### WARNING:

This product was not designed to be left out in the sunlight for extended periods of time. Prolonged UV exposure will rapidly break down the fabric of this product. UV damage is not covered under our warranty.

**WARNING : NEVER LEAVE CHILDREN UNATTENDED.**

**AGES 3 AND UP RECOMMENDED.**

Play tent for indoor and outdoor use.

Keep all Flame and Heat away from tent and tent fabric.

This tent meets flammability requirements of CPAI-84.

**THIS TENT IS NOT FIRE PROOF.**

**IF LEFT IN OPEN FLAME THE TENT WILL BURN.**

**CAUTION:** Never use any fuel-burning or oxygen- consuming devices, or any devices that produce fumes, including stoves, lanterns, candles, hibachis or heaters in or around your tent. This can result in carbon monoxide poisoning, injury or death.

**MADE IN CHINA.**